



On the PCB there are some wrong values of the components.

R11 and R12: right value 470 Ohms

C12: right value 47 nF

C6: right value 100 nF



* not needed if electret mic. is used

** make short if electret mic. is used

Values for UHF:

L1, L2, L3 = 3 turn /@3mm

C16, C20 = 6p8 pF

C17, C18 = 12 pF

ENKODER1